

50Hz 230V calefacción

①	②	Temperatura de aire interior [°C DB]											
		16°C		18°C		20°C		21°C		22°C		24°C	
		TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
		kW	kW	kW	kW	kW	kW	kW	kW	kW	kW	kW	kW
2.0+2.5+2.5+3.5	-15.0	6.24	2.34	6.11	2.36	5.96	2.40	5.89	2.41	5.82	2.42	5.68	2.44
	-10.0	7.42	2.47	7.27	2.49	7.14	2.51	7.06	2.54	6.99	2.55	6.84	2.57
	-5.0	8.58	2.59	8.45	2.62	8.30	2.65	8.23	2.66	8.16	2.68	8.02	2.71
	0.0	9.76	2.72	9.61	2.75	9.47	2.78	9.40	2.79	9.33	2.80	9.18	2.84
	6.0	11.16	2.87	11.02	2.91	10.87	2.93	10.81	2.94	10.73	2.96	10.59	2.99
	10.0	12.10	2.98	11.95	3.00	11.81	3.04	11.74	3.05	11.67	3.06	11.52	3.09
	15.0	13.26	3.11	13.13	3.13	12.98	3.16	12.91	3.18	12.83	3.19	12.69	3.22
2.5+2.5+2.5+2.5	-15.0	6.33	2.30	6.19	2.34	6.05	2.36	5.98	2.37	5.91	2.39	5.77	2.42
	-10.0	7.48	2.44	7.34	2.46	7.20	2.50	7.12	2.51	7.06	2.52	6.92	2.55
	-5.0	8.63	2.57	8.49	2.59	8.35	2.62	8.28	2.64	8.21	2.66	8.07	2.68
	0.0	9.78	2.69	9.64	2.73	9.50	2.75	9.43	2.77	9.36	2.78	9.22	2.81
	6.0	11.16	2.85	11.02	2.89	10.88	2.91	10.81	2.92	10.74	2.94	10.59	2.97
	10.0	12.08	2.96	11.94	2.99	11.80	3.02	11.73	3.03	11.66	3.05	11.52	3.07
	15.0	13.23	3.10	13.09	3.12	12.95	3.15	12.88	3.17	12.81	3.18	12.66	3.21
2.5+2.5+2.5+3.5	-15.0	6.34	2.30	6.20	2.32	6.05	2.36	5.98	2.37	5.91	2.38	5.78	2.41
	-10.0	7.48	2.43	7.34	2.46	7.21	2.48	7.13	2.51	7.06	2.52	6.92	2.54
	-5.0	8.64	2.56	8.49	2.59	8.35	2.62	8.28	2.63	8.21	2.65	8.07	2.68
	0.0	9.78	2.69	9.64	2.73	9.50	2.75	9.43	2.77	9.36	2.78	9.22	2.81
	6.0	11.16	2.85	11.03	2.89	10.88	2.91	10.81	2.92	10.73	2.94	10.59	2.97
	10.0	12.10	2.96	11.96	2.99	11.82	3.02	11.74	3.04	11.67	3.05	11.52	3.07
	15.0	13.27	3.10	13.13	3.12	12.98	3.15	12.91	3.17	12.84	3.18	12.70	3.21

Símbolos

TC: Capacidad total [kW]

PI: Consumo [kW]

① Combinaciones de unidades interiores

② Temperatura del aire exterior [°C BH]