

50Hz 230V calefacción

①	②	Temperatura de aire interior [°C DB]											
		16°C		18°C		20°C		21°C		22°C		24°C	
		TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
		kW	kW	kW	kW	kW	kW	kW	kW	kW	kW	kW	kW
3.5+3.5+4.2+4.2	-15.0	6.44	2.63	6.29	2.66	6.14	2.70	6.07	2.71	5.99	2.72	5.84	2.76
	-10.0	7.66	2.78	7.51	2.81	7.37	2.84	7.29	2.85	7.22	2.88	7.07	2.91
	-5.0	8.89	2.93	8.74	2.96	8.59	3.00	8.52	3.01	8.44	3.02	8.29	3.06
	0.0	10.11	3.08	9.96	3.10	9.81	3.14	9.74	3.15	9.66	3.18	9.51	3.20
	6.0	11.58	3.26	11.43	3.28	11.28	3.32	11.21	3.33	11.13	3.36	10.97	3.38
	10.0	12.56	3.38	12.40	3.40	12.25	3.44	12.18	3.45	12.10	3.47	11.95	3.50
	15.0	13.77	3.52	13.62	3.56	13.47	3.58	13.40	3.61	13.33	3.62	13.18	3.65

Símbolos

TC: Capacidad total [kW]

PI: Consumo [kW]

① Combinaciones de unidades interiores

② Temperatura del aire exterior [°C BH]