


RXL42J



Indoor



BLK : Black
BLU : Blue
BRN : Brown
GRN : Green
ORG : Orange
RED : Red
WHT : White
YLW : Yellow



Field wiring

C74,C75,C94,C95 : Capacitor
DB1,DB2,DB3 : Diode bridge
FU1,FU2,FU3,FU4,FU5 : Fuse
FU6 : Field fuse
IPM1 : Intelligent power module
L : Live
L1 : Coil
L1R : Reactor
M1C : Compressor motor
S1T : Thermostat
M1F : Fan motor
MRCW,MRM10,MRM20,MR30 : Magnetic relay

N : Neutral
PCB1 : Printed circuit board
Q1L : Overload protector
R1T-R3T : Thermistor
SA1 : Surge arrester
Q31 : IGBT
E1H : Heater
Q1DI : Earth leak detector

V1,V3,V4 : Varistor
X1M : Terminal strip
Y1E : Electronic expansion valve coil
Y1R : Reversing solenoid valve coil
Z1C,Z2C,Z3C,Z4C : Ferrite core
⊕ : Protective earth
S20,S40,S70 : Connector
S80,S90 : Connector
X11A,S1 : Connector

3D079995