


RXLG50K



Z1C-Z5C : Ferrite core
X1M,X2M : Terminal strip
Y1R : Electronic expansion valve coil
V2,V3,V5,V6,V11 : Varistor
FU1,FU2,FU3 : Fuse
FU4,FU5 : Field fuse
FU6 : Fuse
AC1,AC2,U,V,W : Connector
X11A,E1,E2,HR1,HR2 : Earth leak detector
Q1D1 : MRM10,MRM20, MRCW : Magnetic relay

R1T-R3T : Thermistor
S2-S102 : Connector
LEDA : Pilot lamp
S1T : Thermostat
SA2 : Surge arrester
L : Live
N : Neutral
SW1 : Forced operation on/off SW (SW1)
SW4 : Local setting SW (SW4)
E1H : Heater

Notes:
1. Refer to purchasing specification AS303002, unless otherwise specified.

M1C : Compressor motor
M1F : Fan motor
L1R : Reactor
Q1L : Overload protector
PM1 : Power module
PCB1.2 : Printed circuit board
Y1R : Reversing solenoid valve coil
Sheet metal : Terminal strip fixed plate