


RXS60F2V1B



⊕ : Protective earth

Z1C~Z4C : Ferrite core

X1M,X2M : Terminal strip

Y1E : Electronic expansion valve coil

V2,V3,V5,V6,V11 : Varistor

SA2 : Surge arrester

F1U,F2U,FU3 : Fuse

AC1,AC2 : Live

U,V,W,X11A : Neutral

E1,E2 : Connector

HR1,HR2 : Connector

MRM10, MRM20, MRC/W : Magnetic relay

R1T~R3T : Thermistor

S2~S102 : Connector

LEDA : Pilot lamp

L : Live

N : Neutral

S1W : Forced operation on/off switch (SW1)

S4W : Local setting SW (SW4)

M1C : Compressor motors

M1F : Fan motor

L1R : Reactor

Q1L : Overload protector

PM1 : Power module

PCB1, 2 : Printed circuit board

Sheet metal : Terminal strip fixed plate