
## **FTXM50-60M**



- 1. Total width of unit
- 2. Width of unit against the wall