




FTXTP-A




NOTES

The → mark shows the piping direction.


Required space for service and ventilation



Blade angle



Wireless remote control
ARC480A78



Standard location of holes in the wall

