


RX50-71K



C7 : Capacitor
 DB1 : Diode bridge
 FU1,FU2,FU3 : Fuse
 IPM1 : Intelligent power module
 L : Live
 N : Neutral
 M1C (MS 3~) : Compressor motor
 M1F (MS) : Fan motor
 MRM10,MRM20,MR30,MRCW : Magnetic relay
 PAM : Pulse amplitude modulation
 ZF : Noise filter

PCB : Printed circuit board
 PS : Switching power supply
 Q1L : Overload protector
 R1T,R2T,R3T : Thermistor
 S20,S40,S70 : Connector
 S80,S90,X11A : Surge absorber
 SA1 : Varistor
 V1,V2,V3 : Thermistor
 X1M : Terminal block
 Y1E (M) : Electronic expansion valve coil

Y1S : Reversing solenoid valve coil
 Z1C,Z2C,Z3C : Ferrite core
 n=4, n=5 : Number of passes through ferrite core
 D1, D2 : Diode
 E1,E2,S,HL1 : Connection
 HN1,W,V,U : Protective earth
 ⊕ : Earth