


XFQ32A

Cooling air velocity distribution

All round air discharge, air flow direction: horizontal



Cooling air temperature distribution

All round air discharge, air flow direction: horizontal

