

# FXHQ-A

## Remote controller dimensions



### Remote controller holder Installation procedure

(Installation to wall surface)



# Receiver installation procedure Receiver

### Receiver detail

