



**NOTES**

- 1 Selecting a flow outside the curves can cause damage to or malfunctioning of the unit. See also minimum and maximum allowed flow in technical specifications.
- 2 Water quality must be according to EN directive EC 98/83 EC.