



## NOTES

- Over all (dB):  
(B, G, N is already rectified)
- Operating conditons:
  - Power source: Y1: 380-415V 50Hz  
YL: 380V 60Hz
  - JIS Standard
- Measuring place: Anechoic chamber (Conversion value)  
The operating sound is measured in anechoic chamber, if it is measured under the actual installation conditions, it is normally over the set value due to environmental noise and sound reflection.
- Location of microphone

Scale	50Hz
A	54.0
C	62.0

