



## Notes

- 1.The fan characteristics shown are in "fan only" mode.
- 2.ESP: External Static Pressure
- 3.The air flow is factory-set to 'standard'. It is possible to switch between 'standard ESP' and 'high ESP' by remote controller setting.