



FXHA100A


Air velocity distribution (cooling)
Air flow direction: horizontal



Air temperature distribution (cooling)
Air flow direction: horizontal



Air velocity distribution (heating)
Air flow direction: vertical



Air temperature distribution (heating)
Air flow direction: vertical

