


Air flow auto adjustment



- ① Upper limit of ESP by air flow auto adjustment
- ② Lower limit of ESP by air flow auto adjustment