

Nr.	Item	Type		FXMQ20,25,32	FXMQ40	FXMQ50,63,80	FXMQ100,125
1	Air discharge adaptor for round ducts			KDAJ25K36A	KDAJ25K56A	KDAJ25K71A	KDAJ25K140A
Operation control							
Nr.	Item	Type		FXMQ20,25,32	FXMQ40	FXMQ50,63,80	FXMQ100,125
1	Remote control	Wired		BRC1D528 / BRC1C62 (*5)			
				BRC1E53A7 (*6)			
				BRC1E53B7 (*7)			
				BRC1E53C7 (*8)(*11)			
				BRC1H51 (*12)			
				BRC1H81 (*13)			
	Wireless	HP	BRC4C65				
CO		BRC4C66					
2	Simplified remote control (with operation mode selector button)			BRC2E52C7 (*9)(*11)			
3	Simplified remote control (without operation mode selector button)			BRC3E52C7 (*9)(*11)			
4	Optional PCB for external electric heaters, humidifiers and/or hour meters			EKRP1B2A (*1) (*2) (*3) (*4)			
5	Adaptor for wiring (interlock for fresh air intake fan)			KRP1C64 (*4)			
6.1	Wiring adaptor for electrical appendices ·(1)·			KRP2A51 (*2) (*4)			
6.2	Wiring adaptor for electrical appendices ·(2)·			KRP4A51 (*4)			
7	Remote sensor			KRCS01-4B			
8	Central remote control			DCS302CA51 / DCS302CA61 (*5)			
8.1	Electrical box with earth terminal (-3· blocks)			KJB311A			
9	Unified ON/OFF controller			DCS301BA51 / DCS301BA61 (*5)			
9.1	Electrical box with earth terminal (-2· blocks)			KJB212A			
10	Schedule timer			DST301BA51 / DST301BA61 (*5)			
11	External adaptor for outdoor unit (installation on indoor unit)			DTA104A61 (*4)			
12	PCB for multi-tenant indoor units			DTA114A61 (*4)			
13	Mounting plate for adaptor PCB			KRP4A96			
14	Digital input adaptor			BRP7A51 (*4) (*10)			
15	Modbus interface DIII			EKMBDXA7V1			

(*1) Electric heaters and humidifiers are field-supplied. Do not install them inside the equipment (refer to installation manual ·EKRP1B2A·).

(*2) When installing electric heaters, an optional PCB for external electric heaters (·EKRP1B2A·) is required for each indoor unit.

(*3) Electric heaters cannot be used in combination with cooling-only VRV systems.

(*4) These options require mounting plate ·KRP4A96·.

Maximally ·2· optional PCBs can be mounted.

(*5) ·BRC1C62, DCS302CA61, DCS301BA61 & DST301BA61·: only for the Middle East region.

(*6) Included languages are: English, German, French, Italian, Spanish, Portuguese, and Dutch.

(*7) Included languages are: English, Czech, Croatian, Hungarian, Slovenian, Romanian, and Bulgarian.

(*8) Included languages are: English, Russian, Greek, Turkish, Polish, Albanian, and Slovak.

(*9) Included languages are:

Language pack ·1·: English, German, French, Dutch, Spanish, Italian, and Portuguese.

With PC cable ·EKPCAB3· in combination with the Updater PC software, you can additionally change the language to:

Language pack ·2·: English, Bulgarian, Croatian, Czech, Hungarian, Romanian, and Slovenian.

Language pack ·3·: English, Greek, Polish, Russian, Serbian, Slovak, and Turkish.

(*10) Only possible in combination with ·BRC2/3E52C7· or ·BRC1E53A/B/C7·.

(*11) Language pack ·3· of controller ·BRC1E53C7· is different from that of controller ·BRC2/3E52C7·.

(*12) Included languages are: English, German, French, Dutch, Spanish, Italian, Greek, Portuguese, Russian, and Turkish.

(*13) Included languages are: English and Arabic

Contents of the accessory bag

Description	Quantity
	FXMQ20,25,32,40,50,63,80,100,125
Hexagon tapping screw (·M5x16·)	16
Round plain washer for wood	8
Installation and operation manual	1
Hose band clamp	1
Joint insulation (gas)	1
Joint insulation (liquid)	1
Drain hose	1
Drain hose sealing material	1
Sealing material	2