

FXNQ-A

Tamaño de la unidad	Exterior °CBS	Temp. ambiente interior													
		14.0 BH		16.0 BH		18.0 BH		19.0 BH		20.0 BH		22.0 BH		24.0 BH	
		20.0 BS		23.0 BS		26.0 BS		27.0 BS		28.0 BS		30.0 BS		32.0 BS	
		TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
15	35.0	1.1	1.1	1.4	1.3	1.6	1.4	1.7	1.5	1.8	1.4	1.8	1.4	1.9	1.4
20	35.0	1.5	1.4	1.8	1.6	2.1	1.8	2.2	1.9	2.3	1.9	2.4	1.7	2.4	1.8
25	35.0	1.9	1.6	2.3	1.9	2.6	2.1	2.8	2.1	3.0	2.2	3.0	2.1	3.1	2.0
32	35.0	2.4	1.9	2.9	2.2	3.4	2.4	3.6	2.6	3.8	2.6	3.9	2.5	4.0	2.5
40	35.0	3.0	2.5	3.6	2.8	4.2	3.3	4.5	3.3	4.7	3.2	4.9	3.1	5.0	3.2
50	35.0	3.8	3.1	4.5	3.5	5.2	3.9	5.6	4.0	5.9	4.0	6.0	3.9	6.2	3.7
63	35.0	4.8	3.8	5.7	4.3	6.6	4.8	7.1	4.9	7.5	4.8	7.7	4.8	7.8	4.8

TC: Capacidad total (kW)

SHC: Capacidad de calefacción sensible (kW)