

**Combinación estándar**

		RXYQ5P	RXYQ8P8	RXYQ10P	RXYQ12P	RXYQ14P	RXYQ16P	RXYQ18P
Bomba de calor	RXYQ5P	1						
	RXYQ8P8		1					
	RXYQ10P			1				
	RXYQ12P				1			
	RXYQ14P					1		
	RXYQ16P						1	
	RXYQ18P							1
Combinación múltiple con 2 unidades exteriores	RXYQ20P8		1		1			
	RXYQ22P			1	1			
	RXYQ24P				2			
	RXYQ26P8		1					1
	RXYQ28P			1				1
	RXYQ30P				1			1
	RXYQ32P					1		1
RXYQ34P						1	1	
RXYQ36P							2	
Combinación múltiple con 3 unidades exteriores	RXYQ38P8		1		1			1
	RXYQ40P			1	1			1
	RXYQ42P				2			1
	RXYQ44P8		1					2
	RXYQ46P			1				2
	RXYQ48P				1			2
	RXYQ50P					1		2
RXYQ52P						1	2	
RXYQ54P							3	