

Compatibility list

Compatibility list	Outdoor units		BS-A14AV1B (Ed.6)	BS-A14AV1B (Ed.6)	BS-A14AV1B9 (Ed.7)
Type	Master	Slave	BS-A14AV1B (Ed.6)	BS-A14AV1B9 (Ed.7)	BS-A14AV1B9 (Ed.7)
Single unit	RE(M/Y)A-A (Ed.6)	-	O*	X	X
	RE(M/Y)A-A9 (Ed.7)	-	O** ⁽¹⁾	O** ⁽¹⁾	O** ⁽²⁾
Multi unit	RE(M/Y)A-A (Ed.6)	RE(M/Y)A-A (Ed.6)	O*	X	X
	RE(M/Y)A-A (Ed.6)	RE(M/Y)A-A9 (Ed.7)	O*	X	X
	RE(M/Y)A-A9 (Ed.7)	RE(M/Y)A-A (Ed.6)	O** ⁽¹⁾	O** ⁽¹⁾	O** ⁽²⁾
	RE(M/Y)A-A9 (Ed.7)	RE(M/Y)A-A9 (Ed.7)	O** ⁽¹⁾	O** ⁽¹⁾	O** ⁽²⁾

Notes

O: Allowed

O*: System certified according to ·Ed.6·

O**: System certified according to ·Ed.7·

X: Not allowed (error generated)

(1) In case ventilated enclosure is applied, the periodical air flow rate check is still required.

(2) In case ventilated enclosure is applied, the periodical air flow rate check can be avoided via special setting.