

# Compatibility list: ·VRV4· heat pump - ·RA DX· indoor unit

Configuration		Indoor unit type	
<b>·RA· indoor unit</b>	Wall-mounted	<i>Emura</i>	FTXJ20A*
			FTXJ25A*
			FTXJ35A*
			FTXJ42A*
			FTXJ50A*
		<i>Perfera (FTXM)</i>	FTXM20(R/A)
			FTXM25(R/A)
			FTXM35(R/A)
			FTXM42(R/A)
			FTXM50(R/A)
			FTXM60(R/A)
		<i>Stylish</i>	FTXA20C
			FTXA25C
			FTXA35C
			FTXA42C
	Floor-standing	<i>Perfera (FVXM)</i>	CVXM20(A/B)*
			FVXM25(A/B)*
			FVXM35(A/B)*
			FVXM50(A/B)*
FVXM50(A/B)*			

**Remark**

The limitations on the use of ·RA DX· indoor units with the ·VRV4· Heat Pump are subject to the rules set out in drawings ·3D079543· and ·3D079540·. If you want to connect ·RA·/·SA· ·DX· cassette, ceiling-mounted, or duct indoor units, use their ·VRV DX· indoor unit equivalents instead.