


VAM2000FC



Symbols

- OA = Fresh outdoor air
- EA = Exhaust air
- SA = Supply air to room
- RA = Return air from room