

Maintenance space for the heat exchange elements, the air filters and fans

Switch box

Inspection hole
□ 450

Supply air fan

Maintenance cover

Ceiling hook
4-14x40 oval hole

SA
Supply air to room

RA
Return air from room

Sealing

OA
Fresh air from outdoors
(Outdoor air)

EA
Exhaust air to outdoors

Sealing

Damper plate

Exhaust air fan

(Maintenance cover)

(Switch box)

Heat exchange elements

Air filters

REMARK

Be sure to provide the inspection hole (450x450mm) to inspect the air filters, the exchange elements and fans.