

VAM1500-2000J8

Symbols :

OA = Fresh outdoor air

EA = Exhaust air

SA = Supply air to room

RA = Return air from room

