

VAM350-500J8

Symbols:

OA = Fresh outdoor air

EA = Exhaust air

SA = Supply air to room

RA = Return air from room

