
A1P
X1A
X2A
X3A
X11A
X12A
X15A
X16A
X17A
X19A
X20A
X22A
X24A
X25A
X26A
X28A
X31A
X33Y
X30Y
X14A
X1M
X12M
X15M
K1R
K2R
K6R
KPR
KVR
KCR
K4R
K1M
K2M
K5M
M1P
M2P
M4S
R6T
R1T
R1H
R2T
A15P
A2P
A3P
Q1L
Q2DI
F2B
FU1
TR1
Z1C N=3
Outdoor unit
BUH option
BUH option only for *6V & *9W
DHW pump
DHW pump output
Max. load:
2 A (inrush) - 230 V AC
1 A (continuous)
DHW output
Max. load:
0.3 A - 230 V AC
NO valve
NC valve
Shut-off valve
ext. ambient sensor option (indoor or outdoor)
SWB1 cover
only for wired ON/OFF thermostat
only for wireless ON/OFF thermostat
only for ext. sensor (floor or ambient)
only for EKRTR1
only for EKRTRB
only for heat pump convector
Add LWT zone
Main LWT zone
1N~, 50 Hz
230 V AC
6.3 A