



ATXF60-71J
FTXF60-71J

The · ⟶ · mark shows the piping direction.













Required space for service and ventilation











Blade angle





Standard location of holes in the wall