

FWZ-AT
FWR-AT
FWS-AT

Air Temperature (°C DB - °C WB)		27 - 19															
"Water Temperature (Entering °C - leaving °C)"		6 - 11				7 - 12				8 - 13				9 - 14			
Model		Total cooling cap	Sensible cooling cap	Water flow	Water pressure drop	Total cooling cap	Sensible cooling cap	Water flow	Water pressure drop	Total cooling cap	Sensible cooling cap	Water flow	Water pressure drop	Total cooling cap	Sensible cooling cap	Water flow	Water pressure drop
		KW	KW	l/sec	kPa	KW	KW	l/sec	kPa	KW	KW	l/sec	kPa	KW	KW	l/sec	kPa
FW 02 T	Max	2.99	2.08	0.143	25	2.65	1.95	0.126	20	2.29	1.82	0.109	16	1.91	1.68	0.091	11
	Min	0.66	0.43	0.031	2	0.61	0.41	0.029	2	0.56	0.39	0.027	1	0.50	0.36	0.024	1
FW 03 T	Max	5.58	3.84	0.266	35	4.98	3.60	0.237	29	4.33	3.35	0.207	22	3.64	3.09	0.174	16
	Min	0.95	0.61	0.045	2	0.88	0.58	0.042	1	0.81	0.55	0.038	1	0.73	0.52	0.035	1
FW 06 T	Max	7.12	5.11	0.339	29	6.34	4.80	0.302	24	5.51	4.49	0.263	18	4.16	4.16	0.220	13
	Min	1.28	0.83	0.061	1	1.19	0.79	0.057	1	1.09	0.74	0.052	1	0.99	0.70	0.047	1
FW 08 T	Max	11.28	7.90	0.538	38	10.10	7.42	0.482	32	8.83	6.92	0.421	25	7.45	6.40	0.355	18
	Min	1.94	1.26	0.092	2	1.79	1.20	0.086	2	1.65	1.13	0.079	1	1.49	1.06	0.071	1

Air flow at 0Pa