

# ERLA11-14DV3

## ERLA11-14DW1

### ERLA-DV37

### ERLA-DW17

| Reference | Description                      |                           |
|-----------|----------------------------------|---------------------------|
|           |                                  | EBS*(11/16)P(30/50)D(F/G) |
| EKMIKPOAF | Mixing kit – PCB only            | o                         |
| EKMIKPHAF | Mixing kit – PCB with hydraulics | o                         |
| EKMIKHMAF | Hydraulics – mixed pump group    | o                         |
| EKMIKHUAF | Hydraulics – unmixed pump group  | o                         |
| EKMIKBVAF | Balancing vessel                 | o                         |
| EKMIKDIAF | Distributor for balancing vessel | o                         |

#### Notes

- (1) PCB that provides additional output connections:
  - (a) Control external heat source (bivalent operation).
  - (b) Output remote ON/OFF signal space heating/cooling
  - (c) Remote alarm output
- (2) Additional relays to allow bivalent control in combination with an external room thermostat are field-supplied.
- (3) PCB to receive up to -4- digital inputs for power limitation
- (4) Data cable for connection with PC.
- (5) Only 1 remote sensor can be connected: indoor OR outdoor sensor.
- (6) The valve kit is mandatory if a heat pump convector is installed on a reversible model (not mandatory for heating only models).
- (7) -EKRTETS- can only be used in combination with -EKRTR1-
- (8) The backup heater capacity depends on a user interface setting.
- (9) Multi-zoning wired controls
- ~~(10) The WLAN cartridge is supplied in the accessory bag of the unit and is meant to be plugged into the SD card slot on the MMI-2. In case of bad signal reception, the WLAN cartridge can be removed and replaced by the WLAN module.~~
- (11) This kit is mandatory for the UK models.
- (12) Only possible in combination with -EKMIKPOAF-
- (13) Only possible in combination with -EKMIKBVAF- and -EKMIKPHAF- or -EKMIKHUAF-
- (14) Only possible in combination with -HBKIT\*.
- (15) Only possible in combination with -ETVZ\*.
- (16) Only 1 Backup heater can be connected on one unit: 3 or 6\* or 9 kW (\*No 6T1-model applicable). EKECBUCO\*AF is needed to connect the backup heater to the main unit
- (17) Mandatory for installations without a bivalent heat source (oil or gas)

#### Remark

Other combinations than mentioned in this combination table are prohibited.