



A1P	Printed circuit board
A2P	Printed circuit board (fan)
C1	Capacitor
C105	Capacitor
F1U	Fuse ·T,3.15A,250V·
F2U	Fuse ·T,5A,250V·
F3U	Fuse ·T,6.3A,250V·
HAP	Indication lamps
K1R	Magnetic relay
K2R	Magnetic relay
L1R	Reactor
M1F	Motor (indoor fan)
M1P	Motor (drain pump)
R1	Resistor (current sensor)
R2	Resistor (current sensor)
R1T	Thermistor (suction)
R2T	Thermistor (liquid)
R3T	Thermistor (coil)
S1L	Float switch
V1R	Diode bridge
PS	Switching power supply
RC	Signal receiver circuit
TC	Signal transmission circuit
X1M	Terminal strip (power supply)
X2M	Terminal strip (power supply)
X3M	Terminal block (control)
Z1F	Noise filter
Z1C	Ferrite core
Z2C	Ferrite core
Q1DI	Earth leakage breaker
Connector (optional accessories)	
X28A	Connector (power supply for wiring)
X28A	Connector (for wiring)
X35A	Connector (power supply for adaptor)
X50A	Connector (wireless adaptor)

- NOTES**
- : Screw terminal □□ : Connector
 ::■■■■: Field wiring
 - In case of a multi-indoor-unit system with parallel operation, refer to the documentation of the indoor units.
 - For details, refer to the wiring diagram attached to the outdoor unit.
 - When using a central remote control, connect it to the unit according to the installation manual.
 - When connecting the input wires from outside, forced OFF or ON/OFF control operation can be selected by remote control. For more information, refer to the installation manual.
 - For a multi-indoor-unit system with parallel operation, the connection ratio (number of indoor units you can connect to the outdoor unit) is different. Before connecting, refer to the Technical data or the General catalogue.
 - For how to switch between the main unit and the sub units, refer to the installation manual of the remote control.
 - Colours: BLK: black; RED: red; BLU: blue; WHT: white; GRN: green; YLW: yellow; BRN: brown; ORG: orange; PNK: pink