

ETSH16E7
ETSHB16E7
ETSX16E7
ETSXB16E7

Factory-mounted equipment for -ETS(H/X)*12*E* and -ETS(H/X)*16*E*.

Description	ETS(H/X)*12P30E*	ETS(H/X)*12P50E*
Domestic hot water tank -300l integrated-	o	-
Domestic hot water tank -500l integrated-	-	o

Description	ETS(H/X)*16P30E*	ETS(H/X)*16P50E*
Domestic hot water tank -300l integrated-	o	-
Domestic hot water tank -500l integrated-	-	o

Outdoor combination table for -ETS(H/X)*12*E* and -ETS(H/X)*16*E*.

		EPRA08EA(V3/W1)	EPRA10EA(V3/W1)	EPRA12EA(V3/W1)
ETSH12P(30/50)E*	Heating only indoor unit, Std	o	o	o
ETSHB12P(30/50)E*	Heating only indoor unit, bivalent	o	o	o
ETSX12P(30/50)E*	Reversible indoor unit, Std	o	o	o
ETSXB12P(30/50)E*	Reversible indoor unit, bivalent	o	o	o

		EPRA(14/16/18)DAW1*	EPRA(14/16/18)DAV3*
ETSH12P(30/50)E*	Heating only indoor unit, Std	o	o
ETSHB12P(30/50)E*	Heating only indoor unit, bivalent	o	o
ETSX12P(30/50)E*	Reversible indoor unit, Std	o	o
ETSXB12P(30/50)E*	Reversible indoor unit, bivalent	o	o

Kit availability for -E(B/D)LA*E*.

Reference	Description		ETS(H/X)12P*E* ETS(H/X)16P*E*	ETS(H/X)B12P*E* ETS(H/X)B16P*E*
EKECBUAF3V	Inline backup heater 3kW	*(16)	Mandatory	o *(17)
EKECBUAF6V	Inline backup heater 6kW	*(16)	Mandatory	o *(17)
EKECBUAF9W	Inline backup heater 9kW	*(16)	Mandatory	o *(17)
EKECBUCO1AF	Inline BUH connection kit TGS/TGL		Mandatory	o *(17)
EKRPIHBAA	Digital I/O PCB	*(1) (2)	-	-
EKRPIAHTA	Demand PCB	*(3)	o	o
BRC1HHDA*	HCI (Human Comfort Interface)	*(4)	o	o
EKPCCAB4	PC cable	*(5)	o	o
KRCS01-1	Remote indoor sensor	*(5)	o	o
EKRSCA1	Remote sensor for outdoor		o	o
EKCC8-W	Universal centralised user interface		o	o
DCOM-LT/IO	DCOM gateway		-	-
DCOM-LT/MB	DCOM gateway		-	-
EKCC8-W	Cascade control		o	o
EKHVCONV4	Conversion kit: heating only to reversible		-	-
FWXV10-15-20ATV3	Heat pump convector	*(6)	o	o
FWXT10-15-20ATV3	Heat pump convector	*(6)	o	o
FWXM10-15-20ATV3	Heat pump convector	*(6)	o	o
EKVKHPC	Heat pump convector valve kit		-	-
EKRTRWA	Wired room thermostat		o	o
EKRTR1, EKTRTB	Wireless room thermostat		o	o
EKRTE5	External sensor room thermostat	*(7)	o	o
EKWUFHTA1V3	Multi-zoning base unit 230 V	*(9)	-	-
EKWCTRD1V3	Digital thermostat 230 V	*(9)	-	-
EKWCTRAN1V3	Analogue thermostat 230 V	*(9)	-	-
EKWCVATR1V3	Actuator 230 V	*(9)	-	-
EKRELSG	Relay for Smart Grid		o	o
BRP069A61	LAN adapter with solar connectivity		o	o
BRP069A62	LAN adapter		o	o
BRP069A71	WLAN module	*(10)	o	o
EKUHWG3D	-G3- kit		-	-
AFVALVE1	Freeze protection valve		o	o
ESAE04A01*	Daikin Residential Controller		-	-
156021	Dirt seperator		o	o
EKECBIVCO1AF	Biv Connector Kit		-	-
EKECDBCO1AF	DB connector Kit		o *(18)	o *(18)
EKSRRPS4AB	Drain back solar control pump station		o	o

Reference	Description		ETS(H/X)*12P*E*
EKMIKPOAF	Mixing kit – PCB only		o
EKMIKPHAF	Mixing kit – PCB with hydraulics		o
EKMIKHMAF	Hydraulics – mixed pump group	*(12)	o
EKMIKHUAF	Hydraulics – unmixed pump group	*(12)	o
EKMIKBVAF	Balancing vessel		o
EKMIKDIAF	Distributor for balancing vessel	*(13)	o

NOTES

- PCB that provides additional output connections:
 - Control external heat source (bivalent operation).
 - Output remote ON/OFF signal space heating/cooling
 - Remote alarm output
- Additional relays to allow bivalent control in combination with an external room thermostat are field-supplied.
- PCB to receive up to -4- digital inputs for power limitation
- Data cable for connection with PC.
- Only 1 remote sensor can be connected: indoor OR outdoor sensor.
- The valve kit is mandatory if a heat pump convector is installed on a reversible model (not mandatory for heating only models).
- EKRTETS- can only be used in combination with -EKTRTR1-.
- The backup heater capacity depends on a user interface setting.
- Multi-zoning wired controls
- The WLAN cartridge is supplied in the accessory bag of the unit and is meant to be plugged into the SD card slot on the MMI-2. In case of bad signal reception, the WLAN cartridge can be removed and replaced by the WLAN module.
- This kit is mandatory for the UK models.
- Only possible in combination with -EKMIKPOAF-.
- Only possible in combination with -EKMIKBVAF- and -EKMIKPHAF- or -EKMIKHUAF-.
- Only possible in combination with -HBKIT*.
- Only possible in combination with -ETVZ*.
- Only 1 Backup heater can be connected on one unit: 3 or 6* or 9 kW (*No 6T1-model applicable). EKECBUCO*AF is needed to connect the backup heater to the main unit
- Mandatory for installations without a bivalent heat source (oil or gas)
- Only for ETS*(12/16)P30E*

REMARK

Other combinations than mentioned in this combination table are prohibited.