Electrical specifications of the backup heaters and booster heaters													
Туре					9W		4V						
	Capacity setting			[kW]	1-9	1	- 6		1 - 4.5				
	Capacity stage · ·				9		6	9					
	Capacity stage ·1·			kW	1		1	0.5					
	Capacity stage ·2·			kW	2 2		2		1				
	Capacity stage ·3·			kW	3				1.5				
	Capacity stage ·4·			kW	4								
Capacity stage ·6·			kW		5		5	2.5					
				kW	6		6	3					
	Capacity stage ·7·			kW	7		-	3.5					
Capacity stage ·8				kW	8		•		4				
	Capacity stage ·9·			kW	9		•		4.5				
Backup heater	Minimum time delay between stages	<u> </u>			10s								
	between stages			40s									
	Max net change > ·2· kW				000 4401/	1 000	0.4017	150s					
	Power supply (1)	Voltage			390 - 410V			390 - 410V 220 - 240 V 4.5kW					
	.,				9kW		26.1A ⁽²⁾	C F A	424	4.5KVV 19.6A ⁽²⁾	17A ⁽²⁾	19.6A ⁽²⁾	
		Rated current Phase			13A 3N~	13A		6.5A	13A				
		Frequency			3N~ 1N		√~	3N~ 1N~ 3~ 2~ 50Hz					
			Must comply with national wiring regulation										
	Type of wires									Min. ·4· mm²			
				·5·-wire cable		·3·-wire cable	·5·-wire cable		·3·-wire cable	·4·-wire cable	·3·-wire cable		
						2L+2N+GND	L+N+GND	3L+N+GND	2L+2N+GND	L+N+GND	3L+GND	2L+GND	
	Recommended overcurrent protection				e ·16· A	2-pole ·32· A		4-pole ·16· A	_	4-pole ·20· A	2-pole ·25· A		
	Earth leakage circuit breaker				Must comply with national wiring regulation								
Capacity setting [kW]					3								
Booster heater	Capacity stage · ·				1								
(optional)(·*KHW *· models)	Minimum time delay between stages				Note ⋅3⋅								
· moders)	Nominal running current		+EK*V3	Α	13								
	(1) The above-mentioned power supply of the hydrobox is for the backup heater only.												
		has a separate power supply.											
Notes	(2) The equipment complies with EN/IEC												
	EN/IEC 61000-3-12 European/International Technical Standard setting the limits for harmonic currents produced by equipment connected to public low-voltage systems with input												
		current > 16 A and \leq 75 A per phase.											

