

FXDA-A

Model name	Unit			Power supply		IFM	Power input [W]	
	Hz	Voltage	Voltage range	MCA	MFA	FLA	Cooling	Heating
FXDA10A2VEB	50/60	220-240/220	MAX. 264/MAX. 242 MIN. 198/MIN. 198	0,3	6	0,2	36	36
FXDA15A2VEB				0,4	6	0,3	48	48
FXDA20A2VEB				0,4	6	0,3	68	68
FXDA25A2VEB				0,4	6	0,3	68	68
FXDA32A2VEB				0,4	6	0,3	68	68
FXDA40A2VEB				0,5	6	0,4	75	75
FXDA50A2VEB				0,6	6	0,5	96	96
FXDA63A2VEB				0,6	6	0,5	107	107

Notes

- 1) Voltage range
The units are suitable for use with electrical systems in which the voltage supplied to the unit terminals is not below or above the listed range limits.
- 2) The maximum allowable voltage that is unbalanced between phases is $\cdot 2\%$.
- 3) $MCA = 1.1 \times FLA$
- 4) Select the wire size according to the MCA.
- 5) Use a circuit breaker instead of a fuse.

Symbols

- MCA: Minimum Circuit Ampere [A]
MFA: Maximum Fuse Ampere [A]
FLA: Full Load Ampere [A]
IFM: Indoor fan motor